

# M9450 SERIES

Installation should be performed by a qualified electrician in accordance with the National Electrical Code and relevant local codes.

## ACCRALUME™ (MACS) LAMP MODULE & FINISH SECTION M9450 MODELS INCANDESCENT FLUORESCENT HID

### NOTICE:

**DO NOT CONNECT LAMP MODULE WHILE SYSTEM IS ENERGIZED. TURN OFF POWER PRIOR TO LAMPING.**

**CAUTION:** Temporary cover must remain in housing until ready to connect power module/cord.

1. Remove temporary cover from rough-in-section.
2. Install lamp module support ring into top of rough-in housing. **DO NOT SECURE RING TO HOUSING.**
3. Plug power module/cord into base of lamp module assembly. **PUSH** cord end directly into module base, **DO NOT TWIST.**
4. Place lamp module assembly into support ring of rough in housing. Position module into ring by aligning module pin with support ring slot.
5. Energize the fixture, allowing it to fully reach operating temperature and light output.



**Caution: Avoid looking directly into light source during aiming. Fixture lens may become hot. Avoid contact with bare skin.**

6. Rotate the lamp module and its support ring until desired position is achieved.
7. Once the desired aiming position is determined, secure the aim-lock ring into the housing with the attached fasteners.

**Caution: DO NOT OVER TIGHTEN (20 in-lbs or 2 n-m).**

8. Install the finish door assembly with the fasteners provided.

**Caution: DO NOT OVER TIGHTEN (20 in-lbs or 2 n-m).**

## INSTALLATION DIAGRAM

SUITABLE FOR WET LOCATIONS • IP68   
**ACCRALUME™ (MACS) LAMP MODULE**

